



Antenna Pattern Measurement Helper

136.01.1706.UG

Jun 29, 2017

Antenna Pattern Measurement Helper

One to Two Weeks in Advance

- __ Make sure you have all equipment needed Transponder, GPS, whips.
- __ Check transponder battery & charge > 12 volts (a new battery will be > 13 volts when fully charged)

Day of APM

- __ Synchronize the computer to GPS clock and confirm site and antenna are functioning properly
- __ Quit all applications except SeaSondeController and SeaSondeAcquisition
- __ Stop logging cross spectra, checkmark "Enable Loop Diagnostics"

CONFIGURE RECEIVER

- __ Use SeaSondeController menu Receiver Controller->Receiver APM Configuration
- or
- __ STORE receiver's normal operating settings in AWG register 3 (in SEND box: type save 3, press enter key)
- __ CONFIGURE RECEIVER with APM Settings as follows and then store the settings in AWG register 2:

| SeaSonde Model | Bandwidth | Blanking | Bdly μ s | Attenuation Boat/Walking | Sweep Frequency | Pulse Shaping |
|----------------|-----------|----------|--------------|--------------------------|-----------------|---------------|
| 5MHz | 25kHz | 120 | ~4.75 | 15/30db** | 2Hz | Off |
| 12MHz | 50kHz | 60 | ~4.75 | 15/30db** | 4Hz | Off |
| 25Mhz | 150kHz | 60 | ~4.75 | 15/30db** | 8Hz | Off |
| 42MHz | 150kHz | 60 | ~4.75 | 15/30db** | 8Hz | Off |

Configure Transponder

- __ Connect USB cable between XPNDR and Mac laptop and launch SeaSonde Transponder Application
- __ Configure TRANSPONDER by clicking "INITIALIZE" button in SeaSonde Transponder application

The Default Settings in the Transponder application will place the transponder signal in range cell 10 (± 2 rc's) and approximately 75% to the right of center (DC) in SeaSondeAcquisition spectral doppler.

__ Save settings to the transponder (press STORE button) and verify that they remain after cycling power

CONFIGURE TRANSPONDER ANTENNA as indicated below:

| SeaSonde Model | Antenna Configuration (Boat Run-APM) | **Antenna Configuration (Walking-WAPM) |
|----------------|---|--|
| 5MHz | 12MHz head w/green antenna + OCEAN GND | three 8' white whips on sides and top |
| 12MHz | 12MHz head w/green antenna + OCEAN GND | three 8' white whips on sides and top |
| 25Mhz | White whips (2 - 4' whips on sides + 8' on top) | two 4' white whips on sides and 8' top |
| 42MHz | White whips (2 - 4' whips on sides + 4' on top) | three 4' White whips on sides and top |

__ Turn off all SeaSondes operating at the same frequency that are within range

__ Place transponder > 1 wavelength from receive antenna and test

__ Identify the peak in the Doppler spectra plot and check for Time Series (Lvl) file creation. Save screenshot.

__ Note range cell number, signal strength (dBm) and Doppler bin number of transponder peak

__ Collect two shore-based data points (ends of the arc) with the transponder and handheld GPS

At the Boat

__ Check boat & assemble transponder antenna

__ Install antenna so it is not blocked to either side & configure antenna sea water ground if using green whip

__ Configure (or confirm) Transponder Settings

__ Clear GPS memory then configure the GPS for logging every 1-5 seconds and also to "stop when full"

__ Turn off GPS and proceed to position where antennas are visible from boat

__ Turn handheld GPS receiver on and confirm it is logging data. Place it in safe location with 5+ satellites visible

At the Receiver

__ Boat proceeds to center of arc a few ~ 100-300m offshore to provide good signal for testing

__ Identify the peak in the Diagnostics window, start logging Time Series and check for Lvl file creation

__ Boat proceeds to starting point of 1st arc to begin the pattern

__ Confirm peaks in channels 1, 2 and 3 as transponder travels through its arcs- ideal peak strength -90 to -120dB

Revision History

First Draft Jun 30, 2017

Copyright and Disclaimer

This document is copyrighted(c) by CODAR Ocean Sensors, Ltd and cannot be copied or reproduced in all or partial without expressed written consent by CODAR Ocean Sensors, Ltd.